

# OD-3 OVERDRIVE

## OWNER'S MANUAL



### WARNING!-IMPORTANT SAFETY INSTRUCTIONS BEFORE CONNECTING, READ INSTRUCTIONS

**WARNING:** To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

**CAUTION:** To reduce the risk of fire or electric shock, do not remove screws. No user-serviceable parts inside. Refer servicing to qualified service personnel.

**CAUTION:** This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The lightning symbol within a triangle means "electrical caution!" It indicates the presence of information about operating voltage and potential risks of electrical shock.

The exclamation point within a triangle means "caution!" Please read the information next to all caution signs.

- Use only the supplied power supply or power cord. If you are not sure of the type of power available, consult your dealer or local power company.
- Do not place near heat sources, such as radiators, heat registers, or appliances which produce heat.
- Guard against objects or liquids entering the enclosure.
- Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage points or other risks. Refer all servicing to qualified service personnel.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally or has been dropped.
- The power supply cord should be unplugged when the unit is to be unused for long periods of time.
- Protect the power cord from being walked on or pinched particularly at

plugs, convenience receptacles and at the point where they exit from the apparatus.  
8. Prolonged listening at high volume levels may cause irreparable hearing loss and/or damage. Always be sure to practice "safelistinging".

**Follow all instructions and heed all warnings  
KEEP THESE INSTRUCTIONS!**


## Overdrive OD-3

Thank you for purchasing this nux OD-3 Overdrive. Please read this manual carefully before using the device.

### Overview

- Delivers that warm, natural tube overdrive sound.
- By rotating the knobs you can boost the guitar amp for colorful tone or overdrive itself for unique pedal sound.
- True bypass hardware switching.
- Top loading battery can be changed without tools.
- LED indicator shows status of effect and battery condition.
- The pedal can be powered by a battery or an optional AC adaptor.

## Product Interface




- POWER IN**  
OD-3 requires 9V DC/300 mA with center negative. Use the power supply with identical specifications.

- LEVEL KNOB**  
Control the level of the distorted signal. Set the knob for matching the distortion level to the same level when switching the effect out.
- TONE KNOB**  
Control the amount of high frequency. Clockwise turning adds sharp to the sounds. Counter clockwise turning cuts high frequency for warmer, mellower sounds.
- OUTPUT**  
Connect the OUTPUT of the pedal to your guitar amplifier or the Input of the other effects unit.
- INPUT**  
Connect the INPUT of the pedal to your guitar or some other effects unit with a 1/4-inch mono phone plug.
- LED Indicator**  
Lights up when the pedal is enabled.
- ON/OFF Switch**  
This footswitch is used to turn effect on/off.

## Installing The Battery

Battery is supplied with the unit. The life of battery may be limited, however, since their primary purpose was to enable testing. Insert the batteries as shown in figure, being careful to orient the batteries correctly.

- Remove the old battery from the battery housing, and remove the snap cord connected to it.
- Connect the snap cord to the new battery, and place the battery inside the battery housing.
- When the battery run down, the sound of unit gets distort. If this happens, replace with new battery.
- Battery life can vary depending on battery type.
- The power comes on when you insert the connector plug into the INPUT jack.
- The use of an AC adaptor is recommended as the unit's power consumption is relatively high.



## Specifications

- Input impedance: 1M Ohms
- Output Impedance: 10K Ohms
- Power : One 9V battery or external AC adaptor (9V)
- Dimensions: 121(L) X 77(W) X 48(D) mm
- Weight: 230g

## Precautions

- Environment:
  - Do NOT use the pedal in high temperature, high humidity, or subzero environments.
  - Do NOT use the pedal in the direct sunlight.
- Please do NOT disassemble the pedal by yourself.
- Please keep this manual for future reference.

## Accessories

- Owner's manual
- QC mark
- 9V battery



## IMPORTANT NOTICE TO CONSUMERS

This product has been manufactured according to strict specifications and voltage requirements that are applicable in the country in which it is intended that this product should be used. If you have purchased this product via the internet, through mail order, and/or via a telephone sale, you must verify that this product is intended to be used in the country in which you reside.

**WARNING:** Use of this product in any country other than that for which it is intended could be dangerous and could invalidate the manufacturer's or distributor's warranty. Please also retain your receipt as proof of purchase otherwise your product may be disqualified from the manufacturer's or distributor's warranty.

## Notifications

### THE FCC REGULATION WARNING (for U.S.A.)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## CE mark for European Harmonized Standards

CE mark which is attached to our company's products of AC mains operated apparatus until December 31, 1996 means it conforms to EMC Directive (89/336/EEC) and CE mark Directive (93/68/EEC). And, CE mark which is attached after January 1, 1997 means it conforms to EMC Directive (89/336/EEC), CE mark Directive (93/68/EEC) and Low Voltage Directive (73/23/EEC). Also, CE mark which is attached to our company's products of Battery operated apparatus means it conforms to EMC Directive (89/336/EEC) and CE mark Directive (93/68/EEC).



www.nuxefx.com

Made in China

# OD-3 OVERDRIVE 经典过载效果器

## 使用说明书


www.nuxefx.com

感谢您选择使用NUX OD-3 经典过载效果器。  
在使用本产品之前请仔细阅读本说明书。

### 产品特点

- 实现温暖、自然的电子管过载音效效果。
- 通过调节旋钮可以提升吉他放大器的音色或者使效果器的音色达到过载效果。
- 采用硬件无杂音开关踏板。
- LED灯指示效果器工作状态以及电量。
- 装载电池方便，无需另外的附加工具。
- 可选择电池或交流适配器供电。

### 产品界面




1. 交流适配器插口  
交流转稳定直流的9伏适配器，需外正内负型。
2. LEVEL音量旋钮  
控制效果器的音量。  
当效果器处在工作状态时，可通过此旋钮调节相应的效果音量。
3. TONE音色旋钮  
控制高频量。  
顺时针旋转，可使声音更加尖锐；逆时针旋转，可减少高频量，使声音更加缓和、圆润。
4. DRIVE过载旋钮  
调节失真效果。  
顺时针旋转，增加失真度；逆时针旋转，可减少失真度。
5. OUTPUT输出插口  
用6.35mm的单声道音频插头，使效果器的输出与音箱或者其它的效果器建立连接。
6. INPUT输入插口  
用6.35mm的单声道音频插头，使效果器的输入与电吉他或者其它的效果器建立连接。
7. LED指示灯  
指示效果器状态。灯亮，表示效果开启；灯灭，表示直通状态。
8. 效果激活踏板（真直通）  
激活效果器或切换到直通状态。

### 电池更换

当出现下列情况之一时，请更换电池：

1. 指示灯变暗；
2. 在效果状态下指示灯不亮；
3. 声音变弱、失真严重时。

更换方法见下图：



- 注意：**
1. 更换电池时，请注意电池的极性。
  2. 为了延长电池的使用寿命，请在不使用设备时，拔出设备连接头。
  3. 若要长期放置产品，请把电池取出，以防止电池漏液对产品造成破坏。
  4. 必须使用相适应的交流电源适配器（9V，外正内负）。

### 技术规格

- 输入阻抗: 1兆欧
- 输出阻抗: 10千欧
- 电源: 1颗9V电池或者外接9V交流电源适配器（外正内负）
- 体积: 121(L) X 77(W) X 48(D) mm
- 重量: 230g

### 注意事项

- 使用环境：
  1. 避免在高温、潮湿、零下等恶劣的环境中使用。
  2. 避免在强光下使用。
- 请勿自行拆卸本机。
- 请保存好本手册以便以后查阅。

### 随机附件

- 操作说明书
- 产品合格证
- 9V电池



### 质量承诺

亲爱的nux用户：  
在您使用nux产品时，请仔细阅读产品说明书，当您有任何疑问和困难时，请拨打售后服务热线：  
133 0293 1293

- 一周内出现质量问题可退货退款
- 一月内出现质量问题可调换
- 一年内出现质量问题可免费维修
- 终身享有咨询和维修服务

[请向销售商索取有效购买凭证并予以保存]

### 换修政策

- 一、包换政策：
1. 消费者自购机之日起1个月之内，在正常使用情况下，出现非人为的产品性能故障，且产品外观及包装保持完好的可向所购机的经销商换机。
  2. 消费者在换机时应出示由经销商开出的购机收据及保修卡，否则经销商可以不予更换。
- 二、保修政策：
- 产品在购买之日起1年内，可免费享有维修服务；对于超过1年的产品及人为或不可抗力因素造成损坏的产品，我司可提供有偿维修服务。

深圳市南山区松白路西丽南岗第二工业园A2栋5-6楼  
深圳市蔚科电子科技开发有限公司售后服务部  
邮编：518108

CE FC RoHS

www.nuxefx.com

Made in China